

Mini — How to Use

Step-by-step guide for the semi-automatic Mini wash station (Mini Basic and Mini Platinum).

Use of the machine is at your own risk. We accept no liability for damage to the bicycle or splash water on clothing.

1 Pre-clean (optional, free of charge)

- If your bike is heavily soiled, or you'd like to clean the handlebars and saddle, place it on the Mini Station and use LuftWASH for pre-cleaning.

2 Payment (contactless)

- Choose a payment method on the display (credit card, EC card, Apple Pay, Google Pay, loyalty card, etc.).
- The price of the wash is shown. The wash duration is 5 minutes.
- Hold your card or smartphone to the display to pay.
- After successful payment the blue button on the machine lights up.
- CAUTION: while the machine is active, please do not pay again — this can cause a duplicate charge.

3 Main wash

- Place your bike with the front wheel in the machine; the rear wheel rests on the ramp.
- TIP: the upper splash-guard brushes can be moved aside if a basket, child seat or similar doesn't fit through.
- Press the blue button: the wash starts, the blue button blinks.
- Make sure the front wheel rotates by itself on the wheel-turn unit inside the machine. Let it clean for about 2 minutes.
- TIP: the red button briefly pauses the cleaning (max. 30 sec.) — press the blue button to resume, e.g. to reposition your bike.
- Slowly guide your bike further through the machine until the rear wheel rotates on the wheel-turn unit. Wait for a few more rotations.
- You can keep using the station until the 5-minute wash time is up. The machine then stops automatically and the red button lights up.
- After the wash, tip the water from the ramps back into the machine.

4 Rinse (optional, free of charge)

- Finally, check the cleaning result and clean any hard-to-reach spots by hand if the machine hasn't caught all the dirt.

In case of a fault or emergency, press the red emergency-stop button! The machine stops immediately.

Please contact service: +49 221 650 540 33 · sales@cyclewash.com